

JUMO IGBT Power Converter 200A with amplitude control

B 70.9050.0.2 Operating Manual

1	Contents	3
2	Introduction	5
2.1	Preface	5
2.2	Typographical conventions	6
2.2.1	Warning signs	6
2.2.2	Note signs	6
2.2.3	Performing an action	7
2.3	Order details	8
2.3.1	Standard accessories	8
2.3.2	Required accessories	9
2.3.3	Further accessories	9
2.4	Brief description	10
2.5	Interpretation of the LEDs	11
3	Installation	13
3.1	Important notes on installation	13
3.1.1	Correctly wire all components	13
3.2	Filtering and interference suppression	16
3.3	Ambient conditions	18
3.4	Spacings	20
3.4.1	Opening the housing	21
4	Electrical connection	23
4.1	Screw connections in the power section	23
4.1.1	Suitable cables and cross-sections	25
4.1.2	Electrical isolation	26
4.1.3	Use of residual current protection devices	26
4.1.4	Replacing the two semiconductor fuses	27
4.1.5	Wiring of the screw terminals	28
5	Settings	31
5.1	Operating principle	31
5.2	Setting switches S101, S103, S104, S105, S106 and X106	32
5.3	Subordinate control loop	33
5.4	Load voltage adjustment	33
5.5	Control inputs	34
5.5.1	Combination of external potentiometer and electronic controller	35
5.6	Firing pulse inhibit	36

5.7	Resistance output	36
5.8	Trimmer settings	37
5.8.1	Resistance limiting (R-control)	37
5.8.2	SIC voltage reserve (SIC reserve)	38
5.8.3	Control input adjustment (max. Power adjust)	38
5.8.4	Setting for maximum power (max. Power adjust)	39
5.8.5	Input signal attenuation	39
5.9	Setting the base load (min. Power adjust)	39
5.10	Setting the current limit (max. current adjust)	40
5.11	Total and partial load failure monitoring (load fail adjust)	40
5.11.1	Setting the load fault indication	42
5.12	Safety cut-out in the power section (IGBT)	43
5.13	Adjusting the output level signal (output adjust U^2, P , I^2)	43
6	Technical data	45
6.1	Voltage supply	45
6.2	Control	45
6.3	Fault signal output	45
6.4	General characteristics	45
6.5	Choke data	47
6.6	EMC filter	47
7	Troubleshooting	49

2.1 Preface



Please read this operating manual before commissioning the instrument. Keep the operating manual in a place accessible to all users at all times.

Please assist us in improving this operating manual.

Your comments are highly appreciated.

Phone: +49 661 6003 -727

Fax +49 (0)661 6003-508



The IPC must only be used with the original JUMO choke and an original JUMO supply filter.

Please check that the chosen supply filter is adequate for the maximum current drawn from the electrical supply to avoid it from being overloaded.



Should difficulties arise during start-up, please do not carry out any unauthorized manipulations. This could lead to you losing your warranty rights!

Please contact the nearest subsidiary or the head office.

Service hotline

For technical questions

Phone support in Germany:

Phone: +49 (0)661 6003-300 or -653 or -899

Fax: +49 661 6003 -881729

E-mail: service@jumo.net

Austria:

Phone: +43 1 610610

Fax: +43 1 6106140

E-mail: info@jumo.at

Switzerland:

Phone: +41 1 928 24 44

Fax: +41 1 928 24 48

E-mail: info@jumo.ch



When accessing the inner parts of the unit, please observe the regulations according to DIN EN 61340-5-1 and DIN EN 61340-5-2 „Protection of electrostatic sensitive devices“. Only use **ESD** packaging for transport.

Please note that we cannot accept any liability for damage caused by ESD.

ESD=Electro Static Discharge

2 Introduction

2.2 Typographical conventions

2.2.1 Warning signs

Danger



This symbol is used when there may be **danger to personnel** if the instructions are ignored or not followed correctly!

Caution:



This symbol is used when there may be **damage to equipment or data** if the instructions are ignored or not followed correctly!

ESD



This symbol is used where special care is required when handling **components liable to damage through electrostatic discharge**.

2.2.2 Note signs

Note



This symbol is used when your **special attention** is drawn to a remark.

Reference



This symbol refers to **further information** in other manuals, chapters or sections.

Footnote

abc¹

Footnotes are remarks that **refer to specific points** in the text. Footnotes consist of two parts:
A marker in the text and the foot note text itself.
The markers in the text are arranged as continuous superscript numbers.

2.2.3 Performing an action

Action instruction

* Plug in the
connector

This symbol indicates that an **action to be performed** is described. The individual steps are marked by this asterisk.

Vital text












This text contains important information, and it is vital that you read it before going any further.

2 Introduction

2.3 Order details

The nameplate is glued onto the right panel of the housing.

(1) Basic version		
	709050/83	IGBT power converter 200A (max. load voltage 210V) standard version
	709050/93	Customer-specific version
(2) Voltage supply to the control section		
11	115V AC +15/-20%, 48 ... 63Hz (only for 115V AC in the power section)	
12	230V AC +15/-20%, 48 ... 63Hz	
(3) Voltage supply to power section		
115	115V AC +15/-20%, 48 ... 63Hz	
230	230V AC +15/-20%, 48 ... 63Hz	
400	400V AC +15/-20%, 48 ... 63Hz	
(4) Load voltage		
020	20V DC	
060	60V DC	
090	90V DC	
120	120V DC	
150	150 V DC	
210	210V DC	
270	270V DC	
380	380V DC	
(5) Load current		
200	200A DC	
(6) Extra code for fault signal output		
252	Relay (changeover contact) 3A	
257	Optocoupler $I_{c\ max.} = 2mA$, $U_{CEO\ max.} = 32V$	
<div><div></div><div></div><div></div><div></div><div></div><div></div></div>		
Order code	(1)	(2) (3) (4) (5) (6)
Order example	709050/83	- 12 - 230 - 120 - 200 / 252

2.3.1 Standard accessories

1 Operating Manual

2.3.2 Required accessories

Choke: $L = 0.6 \text{ mH} / I_{\text{Nom}} = 200 \text{ A}$, protection rating IP 20, as per EN 60 529

Dimensions	Connection	Tightening torque for screw terminals	Weight	Sales No.
Height: 190 mm Width: 200 x 385 mm	Via screw terminals from 35 to 95 mm ²	max. 15...20 Nm	approx. 37 kgs	70/00436848

2.3.3 Further accessories

EMC filter

For voltage supply to power section					
Nominal voltage, nominal current	Dimensions (L x W x H)	Tightening torque for screw terminals	Weight	Permissible ambient temperature	Sales No.
115V/250V/440V AC, $I_{\text{Nom}} = 16 \text{ A}$	(255 x 60 x 130) mm	0.6 ... 0.8 Nm	approx. 4 kgs	40 °C	70/00399527
115V/250V/440V AC, $I_{\text{Nom}} = 20 \text{ A}$	(289 x 70 x 140) mm	1.5 ... 1.8 Nm	approx. 5.5 kgs	40 °C	70/00438775
115V/250V/440V AC, $I_{\text{Nom}} = 32 \text{ A}$	(324 x 90 x 160) mm	1.5 ... 1.8 Nm	approx. 9.5 kgs	40 °C	70/00409831
115V/250V/440V AC, $I_{\text{Nom}} = 63 \text{ A}$	(380 x 117 x 190) mm	2 ... 2.3 Nm	approx. 17 kgs	40 °C	70/00409990
115V/250V/440V AC, $I_{\text{Nom}} = 100 \text{ A}$	(445 x 150 x 220) mm	6 ... 8 Nm	approx. 26 kgs	40 °C	70/00431997
For voltage supply to the control section					
115V/250V AC, $I_{\text{Nom}} = 1 \text{ A}$	80 x 45 x 30 mm	-	approx. 120g	40 °C	70/00413620

Semiconductor fuse


2 extra fast semiconductor fuses are installed in the converter, to protect the IPC in the event of an earth short.

The I^2t value of the semiconductor fuse must be less than 20000 A²s!

Sales No. 70/00434229

2 Introduction

2.4 Brief description

Instrument	The JUMO IPC is a IGBT power converter for controlling heater loads that previously required a transformer (either a variable transformer or a combination of transformer and thyristor power unit). Its function is that of an electronic transformer with a pulsed DC output.
Advantages	It combines the advantages of a conventional variable transformer, such as amplitude control which is the sinusoidal current loading, with the advantages of a thyristor power switch, such as current limiting, load monitoring, subordinate control action, etc.
	There is no electrical isolation between the voltage supply and the load voltage.
Application	This power converter is employed wherever large resistive loads need to be switched and no electrical isolation is required between the supply voltage and the load voltage. Thanks to the amplitude control (the current drawn from the supply is always sinusoidal), synchronous clock controls (as for burst-firing operation) and power-factor compensation networks (for the reactive power resulting from phase-control) are no longer required.

2.5 Interpretation of the LEDs

fuse

Two semiconductor fuses are integrated in the IPC, to protect it in the event of an earth short. If an earth short occurs, one or both of the semiconductor fuses will trip. Tripping of one or both of the fuses is indicated by the "Fuse" LED and the drop-out of the fault signal relay.

⇒ Chapter 4.1.4 „Replacing the two semiconductor fuses“

overheat

This LED lights up if the maximum permitted temperature is exceeded. The fault signal relay drops out at the same time. The load output remains disconnected until the temperature has fallen below the limit value again.

⇒ Chapter 3.3 „Ambient conditions“

IGBT

This LED lights up when the electronic safety cut-out of the load circuit has tripped.

(e.g. because of a wiring fault).

The safety cut-out remains activated until the IPC has been completely (all-pole) disconnected from the supply and then switched on again. The fault signal relay drops out at the same time.

⇒ Chapter 5.12 „Safety cut-out in the power section (IGBT)“

current limit

This LED lights up if the converter is working at the current limit.

⇒ Chapter 5.10 „Setting the current limit (max. current adjust)“

load fail

This LED lights up if a total or partial load failure has been detected.

The fault signal relay drops out at the same time.

⇒ Chapter 5.11 „Total and partial load failure monitoring (load fail adjust)“

R-control

This LED lights up if the converter is working at the resistance limit.

⇒ Chapter 5.8.1 „Resistance limiting (R-control)“


SIC reserve

This LED lights up when the IPC has reached its max. load voltage, so there is no longer automatic compensation for ageing at SIC load. The fault signal relay drops out at the same time.

⇒ Chapter 5.8.2 „SIC voltage reserve (SIC reserve)“

Power

This LED indicates that the control section is connected to the voltage supply. It does **not** indicate the status of the power section!



2 Introduction

3.1 Important notes on installation

Safety regulations

- The choice of cable, the installation and the electrical connection of the instrument must conform to the requirements of VDE 0100 "Regulations on the Installation of Power Circuits with Nominal Voltages below 1000 V AC" or the appropriate local regulations.
- The electrical connection must only be carried out by qualified personnel.
- An isolation switch should be wired between the supply and the converter to be able to disconnect the converter from the voltage supply on all poles prior to starting internal work.



Caution!

The converter has 2 power supplies (to the control section and to the power section). Disconnect both supplies (all poles) prior to starting work on the converter.

Allow 1 minute to elapse after switching off prior to starting work on the converter, since potentially fatal voltages could be present in the converter interior and at the terminals.

- Inside the converter, safety gaps meet the requirements for double insulation.
When installing the connecting cable, ensure that the cables are fitted according to regulations and that the safety gaps are maintained.

Electrical supply types

The IPC is suitable for operation with TN and TT supply networks.

- * Carry out installation in accordance with EN 50178.

Fuse protection



- Fuse protection in accordance with the VDE regulations must be installed for the voltage supply to the power section. The supply protection can also be achieved by a circuit-breaker in the supply lead. This must be dimensioned for the power consumption of the power converter and the rated current of the downstream EMC filter.

- Two semiconductor fuses are incorporated to protect the IPC in the event of an earth short.
(The I^2t value of the semiconductor fuse must be smaller than 20000 A²s)!

⇒ Chapter 4.1.4 „Replacing the two semiconductor fuses“

- Provide an appropriate control circuit fuse for **control section lead protection**. The control section consumes approx. 75 VA.


3.1.1 Correctly wire all components

EMC filter



The IPC may only be used in conjunction with a suitable filter (accessories). If a different filter is used, it must be of equal or better characteristics. Otherwise, inductive voltages may be introduced into the supply network. We decline any liability for damage caused as a result.

3 Installation





The EMC filters may only be used for interference suppression of the IPC power converter. Other devices, such as controllers, power supplies etc. must be suppressed, where necessary, with their own EMC filters. Do not wire these devices in parallel to the IPC power converter on the load side of the EMC filter.

The earth leakage current of the IPC power converter with a filter wired into the supply lead is less than 3 mA. If the load conditions result in an earth leakage current greater than 3.5 mA, a fixed supply connection is required as a protection against hazardous potentials (also see EN 50178).

Electromagnetic compatibility conforms to the standards and regulations cited in the technical data.

⇒ Chapter 6 „Technical data“

- * Load wiring (thick) and cables for control inputs (thin) should be routed separately, if possible.

Positioning of the choke	<ul style="list-style-type: none">* The choke should be installed close to the converter.
Connection	<ul style="list-style-type: none">* Check the data given on the nameplate (voltage supply to the control section, voltage supply to the power section, load voltage and load current) against the system data. <p>⇒ Chapter 2.3 „Order details“</p> <ul style="list-style-type: none">* Check the adaptation of the setpoint inputs.* Check the switch settings.
PE connection/ FB connection	<ul style="list-style-type: none">* Provide a direct connection between the PE of the IPC and the PE of the supply network. Connect to the PE terminal of the IPC.* If necessary, interference emission of the IPC can also be minimised by a function equipotential bonding. The function equipotential bonding is connected to the FB terminal of the IPC. <p>⇒ Chapter 3.1.1 „Correctly wire all components“</p>
Choke connection	<ul style="list-style-type: none">* The choke is connected to terminals C and 1C.
Voltage supply	<ul style="list-style-type: none">* Connect the voltage supply to the control section to terminals L1 and N(L2) (X109).* Connect the voltage supply of the power section to terminals U and N(V). <p> An isolation switch should be wired between the supply and the converter to be able to disconnect the converter from the voltage supply on all poles prior to starting internal work!</p> <p>The connection must only be carried out by qualified personnel!</p>
Load connection	<ul style="list-style-type: none">* The load is connected to terminals D and 1D.* The cable between the load and the IPC should be as short as possible and not exceed 50 m. <p> Use a shielded cable to connect to the load, ensure that the shielding is connected to earth on both ends.</p> <p>⇒ Chapter 3.2 „Filtering and interference suppression“ Choosing the suitable cables</p> <p>⇒ Chapter 4.1.1 „Suitable cables and cross-sections“</p>
Control inputs	<p>The terminal strip for control connections (inputs and outputs) have been laid out for safe isolation from the supply (SELV). To prevent the safe isolation from being impaired, ensure that all connected current circuits are also safely isolated. The required auxiliary supplies must be SELV voltages.</p>

3 Installation

Switch-on sequence

The voltage supplies to the control section and to the power section must be switched on simultaneously.



Under no circumstances may the voltage supply to the control section be switched on before the load voltage. This is especially important when operating resistive loads that have a high hot/cold resistance ratio.

3.2 Filtering and interference suppression

System

Compliance with the EMC standards can only be achieved through additional EMC measures.

These include:

- a supply filter in the voltage supply
- a shielded cable for the voltage supply (from the supply filter (load) to the IPC)
- a shielded cable to the load

Compliance with the EMC standards must be tested for the overall system.

Construction

To keep interference emission through conducted and radiated interference below the permissible levels defined in the pertinent EMC standards, constructive measures must be taken in the installation and wiring stages in addition to supply input filtering. Poor earth connection or shielding of the EMC filter will reduce the effectiveness of the interference suppression measures.

The following points should be noted in order to achieve good configuration for EMC purposes:

- * All metallic components of the converter or cabinet must be well bonded for HF currents over a large surface area.
- * The EMC filter should be installed close to the IPC, if possible, on a common metal plate. Route cables for control inputs and signal cables as far apart from each other as possible, and use shielded cables.
- * If possible, do not route power cables in the same cable duct as control or signal cables.
- * The cable between the load and the IPC should be as short as possible and not exceed 50 m.

Earthing

The base plate, the supply filter and the shielding of the supply cable must be earthed to a star point using HF braiding.

Choosing a suitable cable


- If the cable between the filter and the IPC is longer than 300 mm, we recommend to use a shielded cable with the shielding earthed at both ends. Route cables inside the switch cabinet as close as possible to grounded surfaces, otherwise they can act as antennae and radiate interference.

3 Installation

- To achieve a good shielding effect for the cable, only use cables that have shielding made with tinned or nickel-plated copper braiding. The coverage of the shielding should be at least 70%; the lay angle should be 90°. Screens made of steel braiding are not suitable. Earth the shielding of the load cable on both ends.
- The shielding of the control inputs must only be earthed at one end (IPC side). If potential differences exist, install an additional equipotential bonding conductor.

EMV compliant design

The user/owner is responsible for compliance of the specific application with the EMC directive. The diagram below illustrates such a design for type 709050/X3-12-400-XXX-200/XXX with a **Phase / Phase** supply configuration.




3 Installation

3.3 Ambient conditions

Misuse	The instrument is not suitable for use in areas with an explosion hazard (Ex areas).
Mounting site	The installation site should be free from vibration, dust and corrosive media.
Climatic conditions	<ul style="list-style-type: none">- Relative humidity: 5...85 % no condensation (3K3 as per EN 60721)- Max. air inlet temperature 35°C- Ambient temperature range: 5 ... 40 °C (3K3 as per EN 60721)- Storage temperature range: -10...70 °C- The cable between the load and the IPC should be as short as possible and not exceed 50 m.
Power loss	Power loss occurs in the form of thermal discharge at the cooling body of the power converter and has to be discharged at the place of installation (e.g. in the switch cabinet) in accordance with the climatic conditions.

Power loss for IPC 200A, incl. choke and supply filter

$$P_{\text{tot}} (\text{W}) = I_{\text{Load}} (\text{A}) \times \text{power loss factor}$$



Example of the Molybdenum Disilicid heating elements

IPC type: **709050/83-12-400-90-200/252**
Load voltage = 90V
Load current = 200A
Voltage supply to the power section = 400V

Resistive loads and Molybdenum Disilicid heating elements:

Heating element data: Load voltage = 75V; load current = 130A

- * Determine the max. load voltage actually taken (e.g. 75V) and find the point intersecting with the curve for the voltage supply in the power section. The Y axis shows the attendant power loss factor of, e.g., 7.5.

The power loss (W) is obtained by multiplying this power loss factor by the load current (e.g. 130A) that flows through the load resistor at max. load voltage (e.g. 75V)

Power loss = 130(A) x power loss factor

Power loss = 130(A) x 7.5 = **975W**

Example of the SIC heating elements

IPC type: **709050/93-12-400-90-200/252**

Load voltage = 90V

Load current = 200A

Voltage supply to the power section = 400V

P control, P = 9000W

SIC heating elements

SIC heating element data: new: 45V/200A, old 90V/100A; P = 9000W

- * Determine the maximum load voltage actually taken (e.g. 45V) of the new SIC heating element and find the point intersecting with the curve for the voltage supply in the power section. The Y axis shows the attendant power loss factor of, e.g., 6.8.

The power loss (W) is obtained by multiplying this power loss factor by the load current (e.g. 200A)

that flows at max. load voltage (e.g. 45V) through the **new** SIC heating element

Power loss = 200(A) x power loss factor

Power loss = 200(A) x 6.8 = **1360W**

Wall fixing

- * Use 4 hexagonal M6 bolts (at least quality 8.8) to fix the converter vertically on a heat-resistant switch cabinet back panel.




The temperature of the air drawn in through the ventilation grille must not exceed 35° C. Ensure that the inlet air for the built-in ventilators can be taken in from below and escape at the top without obstruction!

3 Installation

Dimensions

Type 709050/X3...



Caution! Hot cooling body!

The cooling body can reach very high temperatures during operation!

3.4 Spacings

- * Allow a clearance of 10 cm from the floor.
- * Allow a clearance of 15 cm from the ceiling.
- * When fitted next to each other, no spacing between the units is required.

3.4.1 Opening the housing


**Caution!**

The converter has 2 power supplies (to the control section and to the power section). Disconnect both supplies (all poles) prior to starting work on the converter.

Allow 1 minute to elapse after switching off prior to starting work on the converter, since potentially fatal voltages could be present in the converter interior and at the terminals.


Caution! Hot cooling body!

- * Disconnect the built-in converter from the voltage supply on all poles
- * Wait for 1 minute
- * Check that no voltage is present
- * Undo the 2 screws from the bottom of the converter




- * Swing up the housing cover from the bottom of the converter

3 Installation



* Lift the cover out of the groove ❶ and take it off forward ❷



4 Electrical connection

4.1 Screw connections in the power section


Tool

- Screwdriver
- Allen key, width across flats 5 mm and 6 mm



The electrical connection must only be carried out by qualified personnel!

- * Disconnect the system from the electrical supply on all poles.



- * Make the connections to the screw terminals only with cables that have a suitable cross-section and are fitted with cable lugs.



An Allen key, width across flats 5 mm, can be used to tighten the screws in the power section at a max. torque of 6-8 Nm.

Conductor cross section with cable lugs: 10 to 50mm²


An Allen key, width across flats 6mm, can be used to tighten the screws in the power section at a max. torque of 15-20Nm.

Conductor cross section with cable lugs: 35 to 95mm²

4 Electrical connection


Phase / N

The diagram shows the wiring for single-phase operation **Phase / N** for type 709050/X3.



Phase / Phase

The diagram shows the wiring for single-phase operation **Phase / Phase** for type 709050/X3.



4.1.1 Suitable cables and cross-sections

PE conductor The cross-section of the PE conductor must be at least as large as the cross-section of the voltage supply conductors to the power section. If the protective earth (PE) conductor is not part of the supply cable or its sheathing, the chosen conductor must have a cross-section of at least 2.5 mm^2 (if mechanically protected) or at least 4 mm^2 (if the PE conductor is not mechanically protected).

⇒ see VDE 0100 Part 540

Control section The screw terminals for the voltage supply to the control section are laid out for a conductor cross-section between 0.5 mm^2 and 2.5 mm^2 . The minimum conductor cross-section must not be less than 0.5^2 mm . Fusing of the cable must correspond to the selected conductor cross-section.

Power consumption is approx. 75 VA.

Power section



The minimum conductor cross-section chosen must be adequate for the maximum conductor current. The electrical connection is made via screw terminals on the converter. We recommend the use of a shielded cable to reduce EMC interference emission.

⇒ Chapter 3.2 „Filtering and interference suppression“ Choosing the suitable cables



The cable cross-section in the load and choke circuits must not be less than the cross-section of the supply leads to the power section!

Calculation formula

$$I_{\text{Supply}} = \frac{\text{maximum load power consumption}}{\text{Voltage supply to power section}} + 2\text{A}$$

Example

$$I_{\text{Supply}} = \frac{3000 \text{ W (heater load)}}{230\text{V (voltage supply to the power section)}} + 2\text{A} =$$

$$I_{\text{Supply}} = 13\text{A} + 2\text{A} = 15\text{A}$$

4 Electrical connection

4.1.2 Electrical isolation

The control section, including the inputs and outputs, as well as all operator controls can be connected to SELV circuits.

The fault signal relay can be connected to SELV or supply potential, without prejudicing the electrical isolation arrangements of the other inputs and outputs.



There is no electrical isolation between the voltage supply of the power section and the load.

Ensure that the metal housing of the oven or combustion chamber is properly earthed.

⇒ Chapter 3.2 „Filtering and interference suppression“ Installation must comply with EMC requirements.

4.1.3 Use of residual current protection devices

The converter is equipped with an internal input rectifier. A short to the housing can result in a residual DC current that blocks the tripping of the conventional residual current protection device. For this reason, any RCD used must be an „all-current sensitive“ version of Type B.

When defining the trip current for the RCD, the leakage currents of the EMC filter caused by the Y capacitors ($<3\text{mA}$) as well as the capacitive currents from the cable shielding have to be taken into account.




See also EN 50178 (VDE 0160):

Protection of electrical equipment through residual current protection devices.

4 Electrical connection

4.1.4 Replacing the two semiconductor fuses

- * Disconnect (all poles) the converter from the voltage supply.
- * Wait 1 minute to allow hazardous voltages to discharge.
- * Check that no voltage is present on the screw terminals.
- * Open the housing as described in Chapter 3.4.1 „Opening the housing“.



- * Undo the 2 screws each for the left and right semiconductor fuse and take the fuse out of its holder.
 - * Replace blown fuses with new ones and retighten the screws at a max. tightening torque of 20 Nm.
 - * Remedy the cause that led to the semiconductor fuse tripping (e.g. earth short in the power section).
 - * Only use original JUMO replacement parts, item No. 70/00434229.
- ⇒ Chapter 2.3.2 „Required accessories“

4 Electrical connection


4.1.5 Wiring of the screw terminals



Position

The following diagram shows the position of the screw connections in the power section, the screw terminals on the PCB as well as the general connection arrangement.



Only tighten the green screw terminals in the control section with a maximum tightening torque of 0.5 to 0.6 Nm!



	Connection for	terminal screw X109	Detail
	Voltage supply Control section	L1 N (L2)	L1 — o L1 N (L2) — o N (L2)
	Connection for	Screw connections in Power section	Detail
	Voltage supply to power section	U N(V)	L1 — o U N (L2) — o N (V)
	Protective earth	PE	PE — o PE
	Functional equipotential bonding ⇒ Chapter 3.1.1 „Correctly wire all components“	FB	FB — o FB

4 Electrical connection

	Choke connection	1C C	
	Load connection	1D - D +	

	Connection for	terminal screw X102	Detail
	Current input (differential input)	1- 2+	
	Voltage input (referred to ground)	3 ground 4+	
	External manual adjustment Potentiometer 5 kΩ	3 Start (ground) 4 slider 5 end (+10V)	
	Firing pulse inhibit (inhibit input) I_K approx. 1mA (break or make contact)	6 ground 7+	
	Output level 0 to 10V (U^2 , P, I^2) I_{max} approx. 2mA	10+ 6 ground	
	Resistance output 0 to 5 V (R) I_{max} approx. 2mA	8 + 6 ground	

	Connection for	Screw terminal X103	Detail
	Load fault output with relay contact rating 230V AC/3A resistive load relay drops out at fault	1 make contact 2 break contact 3 common	
	Load fault output with optocoupler $I_{c max} = 2mA$ $U_{CEO max} = 32 V$	3 collector 1 emitter	


4 Electrical connection

5.1 Operating principle

The **JUMO** IPC can be used wherever a transformer was previously used to reduce the voltage level.

It functions as an electronic transformer that produces a pulsed DC output.

Block diagram



- 1 Supply fuses for the control section
- 2 Supply fuses for the power section
- 3 Semiconductor fuses
- 4 Rectifier
- 5 Choke
- 6 Load
- 7 IGBT module
- 8 Supply voltage for the control electronics
- 9 Voltage converter
- 10 Current converter
- 11 Electrical isolation for control circuitry
- 12 Control electronics
- 13 Adjustable trimmers
- 14 Fault signal output via relay or optocoupler
- 15 Configuration switches
- 16 LED indicators
- 17 Set output level, control inputs, power level output signals
- 18 R-control
- 19 SIC reserve

5 Settings

5.2 Setting switches S101, S103, S104, S105, S106 and X106

<div><div><div>1 2</div><div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div></div><div>3 4</div><div><div></div><div></div><div></div></div></div><div><div>1 2</div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div></div><div><div>3 4</div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div></div></div> <div><div><div>1 2</div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div></div><div><div>3 4</div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div></div></div> <div><div><div>1 2</div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div></div><div><div>3 4</div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div></div></div> <div><div><div>1 2</div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div></div><div><div>3 4</div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div></div></div> <div><div><div>1 2</div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div></div><div><div>3 4</div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div></div></div> <div><div><div>1 2</div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div></div><div><div>3 4</div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div></div></div> <div><div><div>1 2</div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div></div><div><div>3 4</div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div></div></div> <div><div><div>1 2</div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div></div><div><div>3 4</div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div></div></div> <div><div><div>1 2</div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div></div><div><div>3 4</div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div></div></div> <div><div><div>1 2</div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div></div><div><div>3 4</div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div></div></div> <div><div><div>1 2</div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div></div><div><div>3 4</div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div></div></div> <div><div><div>1 2</div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div></div><div><div>3 4</div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div></div></div> <div><div><div>1 2</div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div></div><div><div>3 4</div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div></div></div> <div><div><div>1 2</div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div></div><div><div>3 4</div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div></div></div> <div><div><div>1 2</div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div></div><div><div>3 4</div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div></div></div> <div><div><div>1 2</div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div></div><div><div>3 4</div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div></div></div> <div><div><div>1 2</div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div></div><div><div>3 4</div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div></div></div> <div><div><div>1 2</div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div></div><div><div>3 4</div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div></div></div> <div><div><div>1 2</div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div></div><div><div>3 4</div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div></div></div> <div><div><div>1 2</div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div></div><div><div>3 4</div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div></div></div> <div><div><div>1 2</div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div></div><div><div>3 4</div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div></div></div> <div><div><div>1 2</div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div></div><div><div>3 4</div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div></div></div> <div><div><div>1 2</div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div></div><div><div>3 4</div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div></div></div> <div><div><div>1 2</div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div></div><div><div>3 4</div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div></div></div> <div><div><div>1 2</div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div></div><div><div>3 4</div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div></div></div> <div><div><div>1 2</div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div></div><div><div>3 4</div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div></div></div> <div><div><div>1 2</div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div></div><div><div>3 4</div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div></div></div> <div><div><div>1 2</div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div></div><div><div>3 4</div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div></div></div> <div><div><div>1 2</div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div></div><div><div>3 4</div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div></div></div> <div><div><div>1 2</div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div></div><div><div>3 4</div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div></div></div> <div><div><div>1 2</div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div></div><div><div>3 4</div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div></div></div> <div><div><div>1 2</div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div></div><div><div>3 4</div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div></div></div> <div><div><div>1 2</div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div></div><div><div>3 4</div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div></div></div> <div><div><div>1 2</div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div></div><div><div>3 4</div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div></div></div> <div><div><div>1 2</div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div></div><div><div>3 4</div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div></div></div> <div><div><div>1 2</div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div></div><div><div>3 4</div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div></div></div> <div><div><div>1 2</div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div></div><div><div>3 4</div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div></div></div> <div><div><div>1 2</div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div></div><div><div>3 4</div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div></div></div> <div><div><div>1 2</div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div></div><div><div>3 4</div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div></div></div> <div><div><div>1 2</div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div></div><div><div>3 4</div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div></div></div> <div><div><div>1 2</div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div></div><div><div>3 4</div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div></div></div> <div><div><div>1 2</div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div></div><div><div>3 4</div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div></div></div> <div><div><div>1 2</div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div></div><div><div>3 4</div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div></div></div> <div><div><div>1 2</div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div></div><div><div>3 4</div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div></div></div> <div><div><div>1 2</div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div></div><div><div>3 4</div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div></div></div> <div><div><div>1 2</div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div></div><div><div>3 4</div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div></div></div> <div><div><div>1 2</div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div></div><div><div>3 4</div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div></div></div> <div><div><div>1 2</div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div></div><div><div>3 4</div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div></div></div> <div><div><div>1 2</div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div></div><div><div>3 4</div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div></div></div> <div><div><div>1 2</div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div></div><div><div>3 4</div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div></div></div> <div><div><div>1 2</div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div></div><div><div>3 4</div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div></div></div> <div><div><div>1 2</div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div></div><div><div>3 4</div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div></div></div> <div><div><div>1 2</div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div></div><div><div>3 4</div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div></div></div> <div><div><div>1 2</div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div></div><div><div>3 4</div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div></div></div> <div><div><div>1 2</div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div></div><div><div>3 4</div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div></div></div> <div><div><div>1 2</div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div></div><div><div>3 4</div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div></div></div> <div><div><div>1 2</div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div></div><div><div>3 4</div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div></div></div> <div><div><div>1 2</div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div></div><div><div>3 4</div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div></div></div> <div><div><div>1 2</div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div></div><div><div>3 4</div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div></div></div> <div><div><div>1 2</div><div><div></div><div></div></div></div></div>

5.3 Subordinate control loop

Subordinate control loops are primarily used to eliminate or compensate for external disturbances, such as fluctuations in the supply voltage and alterations in resistance that have a negative effect on the operation of the control loop.

Factory setting A subordinate U^2 control loop is factory set, however, also the P or I^2 control loop is possible.

Control type	Internal switch S101			Application
	S1	S2	S3	
U^2	1	0	0	- positive TC, Molybdenum Disilicid
				- $R \approx \text{constant}$ - brightness controls
P	0	1	0	- general application, required for SIC loads and automatic compensation for ageing.
I^2	0	0	1	- negative TC

■ factory setting

5.4 Load voltage adjustment

Switch S101-7 can be used to adjust the load voltage.

If the max. load voltage required is less than 75% of the load voltage $U_{L\text{ Nom}}$ as per type code, then S 101-7 must be opened.

If the maximum required load voltage is 75% or more of the nominal load voltage $U_{L\text{ Nom}}$ as per type code, then S 101-7 must be closed.

Factory setting S101-7 is closed.

5 Settings

5.5 Control inputs

The internal switches S8, S9 and S104 are used to adapt the converter to the available control signal (controller output signal).

The voltage and current inputs are separated from one another. The current inputs (+,-) are arranged as differential inputs, i. e. they can have a maximum common mode voltage of 7 V with respect to the common ground potential (\perp). If the current and voltage inputs are used at the same time, their effect will be cumulative.

Control signal		Internal switches		
Signal start	Signal end	S8	S9	S104
0 mA	20 mA	0	1	1
4 mA	20 mA	0	0	2
0 V	10 V	0	1	1
2 V	10 V	0	0	2
0 V	5 V	1	1	1
1 V	5 V	1	0	2


■ factory setting

Analog control inputs

The converter can be controlled through the following signals (continuous power control):

- voltage signal (terminals 3, 4)
- current signal (terminals 1, 2)
- 5 k Ω potentiometer (terminals 3, 4, 5)


For this purpose, a 10 V source is provided on terminal 5.
(switch settings are as for a 0 ... 10 V signal)



5.5.1 Combination of external potentiometer and electronic controller

Controller with current output

The voltage input (terminals 3, 4) in conjunction with the internal 10 V source and a 5 k Ω potentiometer is used as a manual control input.



Switch	S _a	S _b
Automatic mode	open	open
Manual mode	closed	closed



To prevent unintended oversteering when switching over to the manual mode, S_a should be mechanically linked to S_b. Otherwise both signals will briefly cumulate.

Controller with voltage output

Only the voltage input of the converter is used. Manual operation requires a 5 k Ω potentiometer connected to terminals 3 and 5.

Switch	S _c
Automatic mode	Position 1
Manual mode	Position 2

5 Settings

5.6 Firing pulse inhibit

The firing pulse inhibit function provides a simple way of switching to high power levels.



In order to be able to disconnect a system from the supply voltage, a circuit-breaker or main switch for all-pole disconnection must be wired into the supply feed!



If the output power is simply removed by inhibiting the firing pulses, this does not provide electrical isolation from the voltage supply! The terminals D or 1D may still carry dangerous voltage from the supply.

A contact between connections 6 and 7 can be used to switch off the load. The external contact can be a make or break contact, depending on the position of S105.

External contact	Internal switch S105	Response
Make (a)	Position 1	The load is permanently switched off when the contact is closed
Break (b)	Position 2	The load is permanently switched off when the contact is open

■ factory setting


Factory setting S105 is in position 1

5.7 Resistance output

When the converter is operating within rated limits, the resistance output has a voltage of 4 ... 5 V.

5.8 Trimmer settings

The converter has 6 trimmers that can be adjusted by inserting a screwdriver blade (maximum blade width: 2 mm) through openings in the housing.



5.8.1 Resistance limiting (R-control)

The switch S101-10 can be used to activate a limiting of the output power depending on the resistance value R when operating Molybdenum Disilicid heating elements, to avoid overheating of the elements in the upper temperature range. Direct measurement of the resistance of the elements allows precise determination of the element temperature. When switch S101-10 is closed, the converter limits its output power as soon as the element resistance (the element temperature) is reached that was set by the trimmer for „resistance control adjust“. In this manner, the heating element is protected from overheating. The "R-control" LED signals the active status of the resistance limiting.

Factory setting

The R-control trimmer is **not** factory-set. An appropriate adjustment must be carried out on site to set the maximum temperature limit for the heating element. This can be carried out with the aid of load voltage and current measurement (resistance measurement) or with the help of a thermal imaging camera.





A **true-rms meter** must be used for measuring voltage, power or current, because the load current is pulsating DC.

A meter calibrated for alternating current (AC) and sinusoidal waveforms will produce false readings!

5 Settings

The adjustment range of the resistance limiting can be set by the R-control trimmer between R_{Nom} and $10 \times R_{Nom}$.

R_{Nom} = nominal voltage / nominal current

Action	Response
Turn „resistance control“ trimmer clockwise 	Limiting at a higher resistance value (higher temperature)
Turn „resistance control“ trimmer counter-clockwise 	Limiting at a lower resistance value (lower temperature)

Factory setting S101-10 is open, R-control is inactive

5.8.2 SIC voltage reserve (SIC reserve)

When SIC heating elements are used, ageing of the elements is automatically compensated for when P-control is chosen for the subordinate control loop (Chapter 5.3).

The resistance of the SIC heating element increases with the operational time. The IPC converter adjusts the load voltage automatically to match the required power output. As soon as the maximum load voltage from the IPC is no longer sufficient to produce the required output power for the SIC heating element, this condition will be signaled by the „SIC reserve“ LED. This indication appears time delayed after approx. 7 minutes.



The fault signal relay drops out at the same time.

The SIC reserve display as well as the fault signal function can be activated by opening the S101-12.

Factory setting S101-12 is closed, and the function is inactive.

5.8.3 Control input adjustment (max. Power adjust)

The „max. Power adjust“ trimmer at the front can be used to adapt the power output of the converter to the maximum output signal of the controller connected before.

Action	Response
Turn the „max. Power adjust“ trimmer clockwise 	more power
Turn the „max. Power adjust“ trimmer counter-clockwise 	less power

Factory setting The trimmer is adjusted so that a 100% controller output signal produces the maximum load voltage (U^2 control is the factory setting for the subordinate control loop).

Correct measurement



A **true-rms meter** must be used for measuring voltage, power or current, because the load current is pulsating DC.
A meter calibrated for alternating current (AC) and sinusoidal waveforms will produce false readings!

5.8.4 Setting for maximum power (max. Power adjust)

- * Apply the maximum controller output signal
- * Turn the „max. Power adjust“ trimmer clockwise or counter-clockwise until the required power is achieved.
- * Turning the „max. Power adjust“ trimmer clockwise will increase the maximum power output.
- * Take care that the red „current limit“ LED remains off, otherwise the circuit is operating in current limiting (current limit), which leaves turning the trimmer clockwise without effect, as the power output will not increase.

5.8.5 Input signal attenuation

- * Turning the „max. Power adjust“ trimmer counter-clockwise will decrease the maximum power output of the converter.


5.9 Setting the base load (min. Power adjust)

Base load setting

Open switch S11 to be able to set a base load.

Turning the „min. Power adjust“ trimmer clockwise will increase the base load setting.

The settable range covers the complete range from 0 to 100 %.



Example:

A heating system is operated with a base load set to 1/3. The remaining 2/3 of the power are regulated by the controller.

Correct measurement



A **true-rms meter** must be used for measuring voltage, power or current, because the load current is pulsating DC.
A meter calibrated for alternating current (AC) and sinusoidal waveforms will produce false readings!



Factory setting

S101-11 is closed, no base load is set

5 Settings

5.10 Setting the current limit (max. current adjust)

- * The front „max. current adjust“ trimmer can be used to limit the rms value of the load current over a range of 10 to 100 % of the rated converter current.
1.5 clockwise turns correspond to increasing the response threshold by approx. 10 % of the rated converter current.

Action	Response
Turn the „max. current adjust“ trimmer clockwise 	The current limit will increase
Turn the „max. current adjust“ trimmer counter-clockwise 	The current limit will reduce

Correct measurement



A **true-rms meter** must be used for measuring voltage, power or current, because the load current is pulsating DC.
A meter calibrated for alternating current (AC) and sinusoidal waveforms will produce false readings!

The red „current limit“ LED is on when current limiting is active.

Factory setting

The trimmer is set to the maximum rated current.



The activation of the current limit can also be used to operate the fault signal relay.

For this purpose, open switch S 101/13.

Factory setting: The activated current limit is only indicated by the red LED (S 101/13 closed)

⇒ Chapter 5.2 „Setting switches S101, S103, S104, S105, S106 and X106“

5.11 Total and partial load failure monitoring (load fail adjust)

Total and partial load failure monitoring for different types of load.

The factory setting of the converter is such that the total and partial load failure states can be detected for resistive loads and loads connected in series. For short-wave infrared radiators, turn switch S106 to position 2.

Factory setting

Switch S106 is in position 1

If the load resistance changes during operation, this will be detected by the partial load monitoring and indicated through the signal output.

The response threshold can be adjusted by the „load fail adjust“ trimmer on the front panel (load fail adjust) between 20 and 100 % of the rated converter current.



The smallest change in resistance that can be detected is 5 % of the nominal load resistance.

Factory setting

The trimmer is set to approx. 20 %.

The signal output provided is a floating contact or an optocoupler, depending on the extra code.

Type: relay

709050 / X3 - XX - XXX - XXX - 200 / 252

Type optocoupler

709050 / X3 - XX - XXX - XXX - 200 / 257

In the case of a load fault, the floating contact drops out, or the collector-emitter path of the optocoupler goes high-resistance.

The signal output is also active if the maximum temperature of the converter is exceeded (overheat), if the safety cut-out in the power section has been triggered or if the semiconductor fuse has blown (fuse).



The functions „SIC voltage reserve exhausted“ or „Current limit active“ can also be applied to the signal output if they are activated as described in the following sections:

⇒ Chapter 5.8.2 „SIC voltage reserve (SIC reserve)“

⇒ Chapter 5.10 „Setting the current limit (max. current adjust)“

⇒ Chapter 7 „Troubleshooting“

Jumper setting	Response
	Underload detection
	Overload detection

factory setting



The total and partial load failure monitoring (underload) also allows overload monitoring. For this purpose, both jumpers on the pin strip X106 must be turned through 90°.

⇒ Chapter 5.2 „Setting switches S101, S103, S104, S105, S106 and X106“

5 Settings

5.11.1 Setting the load fault indication




The partial load setting must be made after the current limit has been set. If the current limit setting is changed, this will also affect the setting of the partial load fault detection. This must be corrected accordingly, if necessary.

- * Connect the load
- * Provide a full control signal (e.g. 20 mA at the control input)
- * Adjust the „load fail adjust“ trimmer such that the yellow „load fail“ LED just extinguishes.
 - Turn clockwise = LED lights up
 - Turn counter-clockwise = LED extinguishes
- * If necessary, continue turning counter-clockwise to reduce the activation threshold. 1.5 turns of the potentiometer change the load current by approx. 10 % of the converter rated current.

Alternative setting option:

To simulate a load fail, adjust the „load fail adjust“ trimmer such that the yellow „load fail“ LED lights up.



The smallest change in resistance that can be detected is 5 % of the nominal load resistance.

5.12 Safety cut-out in the power section (IGBT)

If there is a fault in the choke or the control electronics, the output voltage is switched off between terminals D and 1D.



However, terminals D and 1D may still carry dangerous voltage from the supply. They are not electrically isolated from the supply!

This state is indicated by the „IGBT“ LED, and the fault signal relay drops out. This safety cut-out remains activated even when the fault has been remedied. It can only be reset by disconnecting the voltage supply.

* Switch the device off briefly, and then on again

5.13 Adjusting the output level signal (output adjust U^2 , P , I^2)

In the factory settings, the output level signal corresponds to the I^2 signal at the output of the converter. It is thus proportional to the power in the load ($R=\text{constant}$).



However, setting P or U^2 instead of the I^2 signals is also possible

⇒ Chapter 5.2 „Setting switches S101, S103, S104, S105, S106 and X106“

Power level output	Internal switches		
	S4	S5	S6
U^2	1	0	0
P	0	1	0
I^2	0	0	1

Output adjust U^2 , P , I^2

The output level signal provides a voltage in the range of 0 to 10V (corresponding to 0 to 100% of the variable being measured). The trimmer „output adjust U^2 , P , I^2 “ on the front panel can be used to set the required end value:

Action	Response
Turn „output adjust U^2 , P , I^2 “ trimmer clockwise 	End value increases
Turn „output adjust U^2 , P , I^2 “ trimmer counter-clockwise 	End value reduces

5 Settings

6.1 Voltage supply

Voltage supply Power section	115V AC +15%/-20% 48 ... 63Hz 230V AC +15%/-20% 48 ... 63Hz 400V AC +15%/-20% 48 ... 63Hz
Voltage supply Control section	115V AC +15%/-20% 48 ... 63Hz, (only with 115V AC in the power section) 230V AC +15%/-20% 48 ... 63Hz
Power consumption, control section	approx. 75 VA
Load voltage $U_{L\text{ rms}}$	20 V DC, 60 V, 90V, 120 V, 150 V, 210 V \approx
Load current $I_{L\text{ rms}}$	200A DC \approx
Load type	Resistive loads

6.2 Control

Control signal	0 (4) ... 20mA $R_i = 50\ \Omega$ 0 (2) ... 10V $R_i = 25k\Omega$ 0 (1) ... 5V $R_i = 12k\Omega$ Manual control through an external 5 k Ω potentiometer
Input signal attenuation	Adjustment range 100 to 20%
Base load setting	0 ... 100 %

6.3 Fault signal output

Relay (changeover contact) without contact suppression	150000 switching actions at a contact rating of 3A/230V 50Hz (resistive load)
Optocoupler output	$I_{C\text{ max}} = 2\text{ mA}$, $U_{CEO\text{ max}} = 32\text{ V}$

6.4 General characteristics

Circuit variants	Single-phase operation
Operating modes	Amplitude control
Subordinate control	As standard: free choice between U^2 -, P-, I^2 control via internal switches
Current limiting	In operation, the load current can be set in the range of 10 ... 100% I_N by a trimmer on the front panel. This limits the rms-value of the load current.
Partial load failure	20 ... 100% of nominal current
R-control	Adjustment range from R_{Nom} to 10x R_{Nom} R_{Nom} = nominal voltage / nominal current
Power level output	As standard: free choice between U^2 -, P-, or I^2 signal via internal switches, adjustable 0 ... 5V to 0 ... 10V, $I_{\text{max}} \approx 2\text{ mA}$, offset deviation: $\leq \pm 5\%$

6.5 Choke data

Type	Dimensions	Connection cross section	Tightening torque for screw terminals	Weight	Sales No.
$L = 0.6 \text{ mH} / I_N = 200\text{A}$ protection rating IP 20 as per EN 60529	Height: 190 mm Width: 200 x 385mm	35...95 mm ²	max. 15...20 Nm	approx. 37 kgs	70/00436848

6.6 EMC filter

For voltage supply to power section						
Nominal voltage, Nominal current	Dimensions (length x width x height)	Connection cross-section	Tightening torque for screw terminals	Weight	Permissible ambient temperature	Sales No.
115V/250V/440V AC, $I_{\text{Nom}} = 16\text{A}$	(255 x 60 x 130) mm	0.25...4 mm ²	0.6 ... 0.8 Nm	approx. 4 kgs	40°C	70/00399527
115V/250V/440V AC, $I_{\text{Nom}} = 20\text{A}$	(289 x 70 x 140) mm	0.5...10 mm ²	1.5 ... 1.8 Nm	approx. 5.5 kgs	40°C	70/00438775
115V/250V/440V AC, $I_{\text{Nom}} = 32\text{A}$	(324 x 90 x 160) mm	0.5...10 mm ²	1.5 ... 1.8 Nm	approx. 9.5 kgs	40°C	70/00409831
115V/250V/440V AC, $I_{\text{Nom}} = 63\text{A}$	(380 x 117 x 190) mm	0.5...16 mm ²	2 ... 2.3 Nm	approx. 17 kgs	40°C	70/00409990
115V/250V/440V AC, $I_{\text{Nom}} = 100\text{A}$	(445 x 150 x 220) mm	10...50 mm ²	6 ... 8 Nm	approx. 26 kgs	40°C	70/00431997
For voltage supply to the control section						
115V/250V AC, $I_{\text{Nom}} = 1\text{A}$	(80 x 45 x 30) mm	via tab connector 6.3 x 0.8mm	-	approx. 120 g	40°C	70/00413620

7 Troubleshooting

What is happening?	Cause / Remedy	Information
Green power LED does not light up	- Voltage supply to control section not connected	⇒ Chapter 4 „Electrical connection“
IPC is not producing any output power although green LED Power is lit and a setpoint value has been provided.	- Voltage supply to power section not connected	⇒ Chapter 4.1 „Screw connections in the power section“
	- Analog control input not connected correctly	⇒ Chapter 4.1.5 „Wiring of the screw terminals“
	- Switch positions for control input S 101/8 and 9 or S104 set incorrectly	⇒ Chapter 5.5 „Control inputs“
	* Check switch for firing pulse inhibit S 105	⇒ Chapter 5.6 „Firing pulse inhibit“
	- Load break - Load short circuit („current-limit“ LED is lit) * Check load and load connections	
IPC is not producing any output power although green power LED is lit, a setpoint value is set and the load fail LED is lit.	- Load break - Load short circuit („current-limit“ LED is lit at the same time) * Check load and load connections	
	- Safety cut-out in the power section	⇒ Chapter 5.12 „Safety cut-out in the power section (IGBT)“
fuse LED is lit	- Semiconductor fuse blown by earth short in the power section/ * remedy wiring fault or earth short in the load	⇒ Chapter 4.1.4 „Replacing the two semiconductor fuses“
IPC is not producing any output power although green power LED is lit, a setpoint value is set and the overheat LED is lit.	- Switch off caused by overheating (clogged or faulty fan) * Check the fan and replace, if necessary - Insufficient supply of fresh air - Inlet air temperature > 35°C * Ensure sufficient ventilation	⇒ Chapter 3.3 „Ambient conditions“

7 Troubleshooting

What is happening?	Cause / Remedy	Information
IPC does not produce full power, although setpoint is set to 100%	- Switch positions for control input S 101/8 and 9 or S104 set incorrectly	⇒ Chapter 5.5 „Control inputs“
	- Control input (max. Power adjust) is not turned clockwise to the stop * Check adjustment	⇒ Chapter 5.8.3 „Control input adjustment (max. Power adjust)“
	- Current limiting active (when the red „current limit“ LED is lit) * Turn the „max. current adjust“ trimmer clockwise	⇒ Chapter 5.10 „Setting the current limit (max. current adjust)“
	- Resistance limiting (R-control) active * Check switch S 101/10	⇒ Chapter 5.2 „Setting switches S101, S103, S104, S105, S106 and X106“
	* Check switch S 103 * Check switch S 101/7	
IPC is producing power, although no setpoint value is set	- Check switches S 101/ 8 and 9 or S104 for control input	⇒ Chapter 5.5 „Control inputs“
	- Base load setting (max. Power adjust) is not turned counter-clockwise to the stop * Check switch S 101/11	⇒ Chapter 5.9 „Setting the base load (min. Power adjust)“



JUMO GmbH & Co. KG

Street address:
Moritz-Juchheim-Straße 1
36039 Fulda, Germany
Delivery address:
Mackenrodtstraße 14
36039 Fulda, Germany
Postal address:
36035 Fulda, Germany
Phone: +49 661 6003-0
Fax: +49 661 6003-607
e-mail: mail@jumo.net
Internet: www.jumo.net

JUMO Instrument Co. Ltd.

JUMO House
Temple Bank, Riverway
Harlow, Essex CM 20 2 TT, UK
Phone: +44 1279 635533
Fax: +44 1279 635262
e-mail: sales@jumo.co.uk
Internet: www.jumo.co.uk

JUMO Process Control, Inc.

8 Technology Boulevard
Canastota, NY 13032, USA
Phone: 315-697-JUMO
1-800-554-JUMO
Fax: 315-697-5867
e-mail: info@jumo.us
Internet: www.jumo.us